Power Monitor Recorder User Manual

Model: PWX-101



Updated: 2023 / 12 / 5 Ver: 1.385

Primestar Energy

1. Introduction



Power Monitor PWX-101 Operations

- 1. Put on power, Turn Power On
- 2. Search WiFi find device, set WiFi SSD Password (Only firest time installation needed)
- 3. Scan QR Code, Into web control pages and works





Power LED :	Red Power On Indictor
WiFi Link :	Blue WiFi Communication Indictor
RESET :	System Manual Reset
WiFi ID :	WiFi ID SSID Reset / Manual Switch Power On/Off
AC Outlets :	Upper for Remote On / Off, Timer Control Outlet Down for Normal continuously on outlet

- > Put-on AC socket : Turn on power switch, Red LED on indicated power-on working now, and the blue WiFi LED on / flashing , means WiFi already working.
- > WiFi setup : First time installation need proceed the WiFi pair-up and enter the WiFi SSID / Password then could into the web control pages.
- > Scan QR Code on top: After complete the WiFi setting, User may scan the QR-Code all time to enter the web control pages automatically. Or may save the web short-cut like_ 192.168.x.x address for next time easily fast recall the Web Control Pages.

2. Installation



> Put-on AC socket : The device applied for AC100 - 250V power line socket After power-on the Red LED on, and blue WiFi LED on, system ready for work.

> Two AC outlets : The upper AC outlet is work for Remote On / Off and Timer Control outlet., and down outlet is continuously on outlet.

All the outlets are included in the power monitor function.

> Power On OK, Go to WiFi setting: Now the PWX-101 ready work, but still need setup the WiiFi environment for first time use,

3. WiFi Setting

- > Clear the old WiFi setup : User may clear the previous WiFi setting data by press the WiFi ID button for 10 seconds until the WiFi LED On then return to original status.
- > Log-in the PWX-101 WiFi hot spot : Turn on the WiFi hot spot search function, search the PWX-101 hot spot entrance like ...



- "ESP32_XXXXX" The head ESP32
 WiFi hot spot is the device chip ID and add with your machine code, please select it for enter WiFi configuration.
- > System will show there is no internet service but it is ok, we just only use it to enter your home WiFi SSID & Password only needed.

> Scan the top QR-Code machine ID for WiFi configuration_



19:59 🖪		الا ن
☆ ●	192.168.4.1	C

WiFiManager

ESP32_761B5AE0



- Scan the top QR Code of machine ID, use browser to open web page for WiiFi Manager and select WiFi configuration.
- > Or user may use browser and type_
 192.168.4.1 for into WiFi Manager page
 by manual operate.

> NOTICES:

Now procedures only available when user connected the ESP32 hot-spot complete.

If it 's not showed, please back previously step to choice the ESP32_xxx of WiFi service again to complete web setting.

> Enter the ESP32 WiFi Manager and select <Configure WiFi > for PWX-101 to home WiFi router connect setting. 19:59 🖪

Mi_FH-2F 🔒 🔒

ê 🛯 📋

A.

goforwildnetis2.4G

ASUS

CHT 20 🔒 🔒

SSID

TP-LINK_60EE50

Password

•••••



Select your home WiFi SSID
 for PWX-101 to connect and
 enter the password then SAVED.

> NOTICES:

Now we selected WiFi hot spot that must be the same as later which user want to enter the PWX-101 web control functions.

If not the same WiFi SSID router that may cause fire wall blocked and unable to connect.

> The WiFi setup complete OK !

\$ 0

192,168,4,1

<u>ار ج</u>

(5

5

Saving Credentials Trying to connect ESP to network. If it fails reconnect to AP to try again



- > Shown as this means WiFi Configure completed, when next time scan QR code it will goto the web page directly.
- > When the WiFi configuration not success, or user and PWX-101 not in the same WiFi hot spot, it may cause miss-connection and unable to reach the web pages service.
- > When too many WiFi hot-spot at home, be sure that user operation computer with PWX-101 in the same WiFi SSID router to make sure the web connection available all time.
- Please repeat the upper procedure for complete the WiFi SSID & Password setting.
- > Again scan top QR Code for enter PWX-101's web function pages.
- > When WiFi setting complete, after scan QR code it will show the connected IP address which get from home WiFi router, and into web page automatically when user opened browser.
- > OK ! Next for web function pages !



<	>	â	₹₽	2	Ξ
	111	(D	<	

> WiFi Setup completed !

Congratulations, when you success enter the web control page of PWX-101, that means system had already work normally now.

> Any time user just scan the QR code then into the web page directly like this.

Or user may save the web IP address which shows on the page_ 192.168.x.x as short-cut, then next time can into web page quickly.

> The IP address like_ 192.168.1.30 is the web address which get from users home WiFi router, so you may save the address as short-cut for directly open this address into the PWX-101.

> WiFi Configuration completed OK !

4. Functions



> HOME : Hourly Power Chart Displays today's hourly power consumption lists

chart, Blue is Power Watt, Red is Power Sum in Watts / Hourh.



Timer	Timer setup page
SETUP	User information setup
DOWNLOAD	Charts Upload / Download
Calculate	Energy Calculator
MOBILE	Cell phone mobile pages



Remote control AC outlets On / Off.

Real-time data:	Power Line Location:	User application names.
		1 1

IP Address **192.168.1.14** The web connecting address.

Voltage User's home AC power line voltage, Default is 110V.

AMP Current power ampere values.

Device Maximum power supply value, default is 1.5KWh.

Power Current measured power consumption of AC Watts.

Ratio% The Consumption / Maximum ratio%.

Today's power consumption summary in KWh.



> Daily / Weekly power recorded chart,



> Displays the Day / Week / Month power recorded chart,

Hour Chart DAY Chart Week Chart MonthChart	PWX-101 Power Control Recorder Timer Setup				
	Timer Set		HOUR (00-23)	MIN (00-59)	Timer Enable
	Timer 1	ON	0	: 0	
Timer Set		OFF	99	43	Enable
SETUP	Timer 2	ON	0	0	
DOWNLOAD		OFF	0	: 0	Enable
Calculate					
MOBILE	> When Enter Hour	>23 o	r Minute >59 ther	n goto 99 = Not W	SET OK
					(C) 2023 PrimeStar Energy

> Timer Setup Page_ Two timer control of Timer1 / Timer2 for setup

ON time : Hour (00-23) : Minute (00-59) Timer_On **OFF time :** Hour (00-23) : Minute (00-59) Timer_Off

Enable : Click for Timer control enabled.



> User Setup : For Modify / Save user's information.

Project	Enter the user's application name.
Voltage	Enter the power line AC voltage, Default is "110" V.
Capacity	Enter the maximum output capacity. Default is "1500" Watts.
Time Zone	Setting the user's home time zone, for auto time correction.
Version	Product version code.

> SET OK : Setup completed, Save user's data !



> Upload / Download page : Hour / Day / Week / Month charts file server.

Select for Upload Upload files from user's local computer.

Download Power Data Records

Update all files to newest before download.

Hourly data	< PowerHour.dat >	Hour / Today	's hourly chart	File Download
Dialy data	< PowerDay.dat >	Day	Daily	Download
Weekly data	< PowerWeek.dat >	Week	Weekly's	Download
Monthly data	< PowerMonth.dat >	Month	Monthly's	Download

10-Min Data < Power10Min.csv > 10-Minutes --- Excel --- Download

Reset 10-Min History Data

Reset the 10-Min history data only.

Delete All Records, Reset !

Delete all data, reset to original status.

× N	Aicrosoft Exce	- Power10N	/lin								- 0	×
	檔案(F) 編輯	(E) 檢視(⊻)	插入① 有	各式(0) 工具	① 資料(D)) 視窗(W)	說明(出)		輸入	需要解答的問	-	- 8
			新細	明體	• 12	- B /	<u>u</u> ≣ ≡		\$%,	:8 :08 t≢ t	= 🖂 • 💩	- <u>A</u> -
	2 🖪 🔁 d	s 🖪 🖤	X B B.	- 🛷 KD + 1	α - 🤮 Σ	- 21 21	1009	6 - 2	_			
	Al	+	fx I	Date			_					
	A	В	С	D	E	F	G	Н	Ι	J	K	L
1	Date	00:00	00:10	00:20	00:30	00:40	00:50	01:00	01:10	01:20	01:30	01:
2	231122	0	0	0	0	0	0	0	0	0	0	
3	231123	96	83	55	40	41	40	40	40	40	40	
4	231124	50	49	48	48	47	46	43	42	40	40	
5	231125	138	84	70	69	72	55	54	53	44	43	
6	231126	160	102	69	43	43	43	43	43	43	43	
7	231127	84	81	83	83	83	71	61	60	59	58	
8	231128	42	42	42	42	42	44	43	42	42	42	
9	231129	147	106	85	40	40	41	40	40	40	40	
10	231130	89	71	75	71	50	39	39	39	39	39	
11	231201	41	40	40	40	40	41	41	41	41	41	
12	231202	106	92	84	41	41	41	41	41	40	40	
13	231203	126	73	69	66	68	66	66	65	54	38	
14	231204	50	49	42	40	38	39	39	39	44	39	
15	231205	0	0	0	0	0	0	0	0	0	0	
16	231206	0	0	0	0	0	0	0	0	0	0	
17	231207	8983.2	9024.3	9063.2	9100.7	9138.7	22.2	58.3	94.9	131.4	167.4	202
18	231208	11474.2	11518.1	11559.9	11597.1	11634.3	9.3	41.2	74.5	108.8	143.4	182
19												
20												
21							1					
22												
23												
24												
25												
•	► ► Power	10Min/					1					

> Download History Data File : The 10-Min History data file, user may download the "Power10Min.csv" file and open by Excel as shown, to make the colorful statistic charts as power analysis documents.

HOUR DAY WEEK	Power Monitor Recorder Energy Calculator	
Month Timer SETUP Download Calculate	 Duration Energy Calculate From 230101 To 999999 Days= 89 Days Energy= 1566.91 KWh Average= 17.61 KWh/Day x @Unit 4.00 Account \$= \$6267.63 Dollars 	- OK SET-
MOBILE	 > Date format Ex: 2023/1/15 Enter "230115" 6-Digits, Ex: 2025/12/1 Enter "251201". > Today always the last Ex: Enter "9999999". > Dollars input Ex: \$ 5.2 Enter "5.20" with 2-Small Digits. 	(C) 2023 PrimeStar Energy

> Energy Calculate : Statistics of power of bill calculation for a period.





> MOBILE pages : Hourly / Daily / Week / Month data graphs, real-time information.

> Web Page Lagged : When the WiFi signal weak or blocked, the web page will display delay or slowly, user may try F5 or reload to refresh page again for re-connection. Some times when system flash working maybe cause WiFi link lagged, but wait for some Seconds will remain normal soon.

供	電記錄器	Powe	r Record	der
Project:	Taiwan	台灣 UTC	+8	
0.30)	32	0.	.01
Amp		Watts	1	KWh
2023	年2月4	E	14 :	47 : 49
	功能設定	Functi	on Setup	
Project	Taiwan 台灣	UTC+8		
Time Zone	UTC+8 台北	北京 新加坡	~	SET 設定
Power	Timer setu	p		ON 🙂
Upload	Upload rec	ord charts t	o PWX	Hint
Download	Download r < PowerDa < PowerWe < PowerMo	record char y.dat > eek.dat > onth.dat >	ts.	Hint
RESET	Reset clear	all datas !		Hint
Download	Goto DOW	NLOAD Pa	age	GO
HOUR	DAY	WEEK	MONTH	HOME

> MOBILE Setup page : Update / Save user inputs.





Enter Timer Setting Page.



> Two Independent Timer : ON Power On Time = HH : MM. OFF Power Off Time = HH : MM. Enable = Tick: Work / Untick: Not Work. SET = After press SET then work.



5. Specifications

Model :	Power Monitor / Data Recorder PWX-101
Measurement :	Internal Close-loop C.T. Current Meter x 1
Range :	AC 100 – 250V / 1 -15 Amp / 10 – 1500 Watt
Voltage :	AC 100 – 250V / 5 Watt
Fuse :	AC 110= 15A / AC220V= 10A
	(For safety issue, official use 10A)
SizeDimension :	L=130 x W=80 x H=30 cm
	L= 52 x W=31.5 x H=11.8 inch
Weight :	500 gm / 1.1 pd



Power Control PWX-103 PWX-104 Monitor Recorder Web Page Control, No need install APP 電力控制記錄器 Power Control Record



I.O.T Internet Products https://3dok.biz/pe/power-monitor/

On-Line Shop <u>https://3dok.biz/pe/shop/</u>



Primestar Energy <u>3dok.biz/pe</u>







綠能之星 能源科技 Primestar Energy Corp.

LINE用戶標準並行動傳碼後。可將您该入好友!

FB_ https://www.facebook.com/groups/130400613282864